

Sampling of Nitrogen-15 and Oxygen-18 in Nitrate

For each sample fill 1 x 0.5 L PE bottle (should contain at least a few mg of nitrate)

1. Fill water in your PE bottle (ca. 4/5 full).
2. Add a few drops of chloroform by pipette.
3. Note date and sampling locality on the bottle.
4. Note addition of chloroform on the bottle.
5. Store in a cool place. Do not freeze!
6. Transport to the laboratory.